



# NATIONAL TERRAZZO & MOSAIC ASSOCIATION

[www.ntma.com](http://www.ntma.com)

800.323.9736

TECHNICAL BULLETIN #G-2

08/13

---

(Formerly TB #O2-A)

## PREPARATION PROCEDURE for FIBER CONCRETE

The primary issue with filament reinforced concrete preparation is to remove any exposed glass or plastic fibers.

1. Shot blast the surface for a maximum profile meeting CSP 4 or 5
2. Razor scrape, cut or burn exposed fiber with a flame gun to remove any exposed fibers
3. Broom/vacuum the residue
4. Prime and install the proposed epoxy system *per manufacturer's instructions*

**General Disclaimer:** *The information provided in the Technical Bulletin is for general informational purposes only. Each project and individual application are unique. All information is provided in good faith: However, NTMA makes no representations or warranties of any kind, express or implied, regarding the accuracy, adequacy, validity, reliability or completeness of any information provided herein.*